UP-VW1236P1

Model No	UP-VW1236P1
Selling Unit	Each
Description	UP-VW1236P1 (UP-RW1236P1) Panasonic Sealed Lead Acid Battery for Standby, UPS
Application	UPS, Standby, Fire Panel, Security
Chemistry	Sealed Lead
Voltage	12V
Unit Hour	76.2Wh
Units Per Unit	One
Nominal Capacity	9.0Ah
Termination	F2, Faston 250 (0.25"/6.3mm spade)
Width	65.5mm
Height	94mm
Length/Breadth/Depth	151mm
Weight	2950g
Outer Quantity	10

Suitable For:

- APC 330XT (2 Batteries Required)
- APC 360SX (2 Batteries Required)
- APC 600 (2 Batteries Required)
- APC 600R (2 Batteries Required)
- APC 600RM (2 Batteries Required)
- APC AP280 (1 Battery Required)
- APC AP330 (1 Battery Required)
- APC AP330XT (1 Battery Required)
- APC AP360 (1 Battery Required)
- APC AP360SX (1 Battery Required)
- APC AP600 (2 Batteries Required)
- APC AP600RM (2 Batteries Required)
- APC APC400 (2 Batteries Required)
- APC APC420 (2 Batteries Required)
- APC BACK-UPS 1200VA (BR1200) (2 Batteries Required)
- APC BACK-UPS 2200 (2 Batteries Required)
- APC BACK-UPS 250VA Intl (BK250i) (1 Battery Required)
- APC BACK-UPS 300 (1 Battery Required)
- APC BACK-UPS 300 (BK300C) (1 Battery Required)
- APC BACK-UPS 300 w/L5-15 (BK300X116) (1 Battery Required)
- APC BACK-UPS 400 (1 Battery Required)
- APC BACK-UPS 400B (1 Battery Required)
- APC BACK-UPS 500 (1 Battery Required)
- APC BACK-UPS 500 (BK500MC) (1 Battery Required)
- APC BACK-UPS 500U (1 Battery Required)
- APC BACK-UPS 500VA Industrial Din Rail UPS (SP500DR) (1 Battery Required)
- APC BACK-UPS 650 (1 Battery Required)
- APC BACK-UPS 900VA (BR900) (2 Batteries Required)
- APC BACK-UPS BK200 (1 Battery Required)
- APC BACK-UPS BK200C (1 Battery Required)
- APC BACK-UPS BK250B (1 Battery Required)
- APC BACK-UPS BK280B (1 Battery Required)
- APC BACK-UPS BK300 (1 Battery Required)
- APC BACK-UPS BK300C (1 Battery Required)
- APC BACK-UPS BK300X116 (1 Battery Required)
- APC BACK-UPS BK300XII (1 Battery Required)
- APC BACK-UPS BK350 (1 Battery Required)
- APC BACK-UPS BK350EI (1 Battery Required)
- APC BACK-UPS BK400 (1 Battery Required)
- APC BACK-UPS BK400B (1 Battery Required)
- APC BACK-UPS BK500 (1 Battery Required)
- APC BACK-UPS BK500M (1 Battery Required)
- APC BACK-UPS BK500MC (1 Battery Required)
- APC BACK-UPS BK650 (1 Battery Required)
- APC BACK-UPS BP280 (1 Battery Required)
- APC BACK-UPS BP280B (1 Battery Required)
- APC BACK-UPS BP350 (1 Battery Required)
- APC BACK-UPS BP420 (1 Battery Required)
- APC BACK-UPS BP420S (1 Battery Required)
- APC BACK-UPS BP500 (all) (1 Battery Required)
- APC BACK-UPS BP500CLR (1 Battery Required)
- APC BACK-UPS BP500LS (1 Battery Required)
- APC BACK-UPS BP500UC (1 Battery Required)
- APC BACK-UPS BP600 (1 Battery Required)
- APC BACK-UPS BP700LS (1 Battery Required)
- APC BACK-UPS BR1000I (2 Batteries Required)
- APC BACK-UPS BR1000-IN (2 Batteries Required)
- APC BACK-UPS BR1500I (2 Batteries Required)
- APC BACK-UPS BR1500-IN (2 Batteries Required)
- APC BACK-UPS BX1000 (2 Batteries Required)
- APC BACK-UPS BX1500 (2 Batteries Required)
- APC BACK-UPS CS 350VA (BK350) (1 Battery Required)
- APC BACK-UPS CS 500 (BK500) (1 Battery Required)
- APC BACK-UPS CS 500 Black (BK500BLK) (1 Battery Required)
- APC BACK-UPS CS BK350 (1 Battery Required)
- APC BACK-UPS CS BK350E1 (1 Battery Required)
- APC BACK-UPS CS BK500 (1 Battery Required)
- APC BACK-UPS CS BK500E1 (1 Battery Required)
- APC BACK-UPS ES 500 (BE500U) (1 Battery Required)
- APC BACK-UPS ES500VA (BE500C) (1 Battery Required)
- APC BACK-UPS ES 650VA USB (BR650BB) (4 Batteries Required)
- APC BACK-UPS ES 725VA Broadband (BE725BB) (4 Batteries Required)
- APC BACK-UPS LS500 (BP500UC) (1 Battery Required)
- APC BACK-UPS LS500 Clear (BP500CLR) (1 Battery Required)
- APC BACK-UPS LS 700 (BP700UC) (4 Batteries Required)
- APC BACK-UPS Powerstack 250 (1 Battery Required)
- APC BACK-UPS PRO 280 (1 Battery Required)
- APC BACK-UPS PRO 280 (BP280IPNP) (1 Battery Required)
- APC BACK-UPS PRO 280BPNP (1 Battery Required)
- APC BACK-UPS PRO 280C (1 Battery Required)
- APC BACK-UPS PRO 280PNP (1 Battery Required)
- APC BACK-UPS PRO 280PNP (BP280PNP) (1 Battery Required)
- APC BACK-UPS PRO 280S (1 Battery Required)
- APC BACK-UPS PRO 280VA (BP280S) (1 Battery Required)
- APC BACK-UPS PRO 350U (1 Battery Required)
- APC BACK-UPS PRO 350VA (1 Battery Required)
- APC BACK-UPS PRO 420 (1 Battery Required)
- APC BACK-UPS PRO 420 (BP420iPNP) (1 Battery Required)
- APC BACK-UPS PRO 420C (1 Battery Required)
- APC BACK-UPS PRO 420PNP (1 Battery Required)
- APC BACK-UPS PRO 420S (1 Battery Required)
- APC BACK-UPS PRO 420VA (BP420S) (1 Battery Required)
- APC BACK-UPS PRO 500 (1 Battery Required)
- APC BACK-UPS PRO 500CLR (1 Battery Required)
- APC BACK-UPS PRO 500U (1 Battery Required)
- APC BACK-UPS PRO 500VA (BP500U) (1 Battery Required)
- APC BACK-UPS PRO BP280C (1 Battery Required)
- APC BACK-UPS PRO BP280IPNP (1 Battery Required)
- APC BACK-UPS PRO BP280PNP (1 Battery Required)
- APC BACK-UPS PRO BP280S (1 Battery Required)
- APC BACK-UPS PRO BP280SUS (1 Battery Required)
- APC BACK-UPS PRO BP280SX116 (1 Battery Required)
- APC BACK-UPS PRO BP420C (1 Battery Required)
- APC BACK-UPS PRO BP420IPNP (1 Battery Required)
- APC BACK-UPS PRO BP420PNP (1 Battery Required)
- APC BACK-UPS PRO BP420S (1 Battery Required)
- APC BACK-UPS PRO BP420SUS (1 Battery Required)
- APC BACK-UPS PRO USB 350VA (BP350U) (1 Battery Required)
- APC BACK-UPS PRO USB 350VA (BP350UC) (1 Battery Required)
- APC BACK-UPS PRO USB BP350UC (1 Battery Required)
- APC BACK-UPS PRO USB BP500CLR (1 Battery Required)
- APC BACK-UPS PRO USB BP500UC (1 Battery Required)
- APC BACK-UPS PRO w/L5-15R (BP280SX116) (1 Battery Required)
- APC BACK-UPS RS1000 (2 Batteries Required)
- APC BACK-UPS RS1000VA (2 Batteries Required)
- APC BACK-UPS RS1500 (2 Batteries Required)
- APC BACK-UPS RS 1500VA (2 Batteries Required)
- APC BACK-UPS RS 800VA Black (BR800BLK) (2 Batteries Required)
- APC BACK-UPS RS 800VA (BR800) (2 Batteries Required)
- APC BE500U (1 Battery Required)
- APC CP15U48D (1 Battery Required)
- APC CP24U12D (1 Battery Required)
- APC CP36U52 (1 Battery Required)
- APC CS350 (1 Battery Required)
- APC GP1270F2 (2 Batteries Required)
- APC LCR12V6.5 (2 Batteries Required)
- APC PCPER (1 Battery Required)
- APC PCPRO (1 Battery Required)
- APC Personal Power Cell (2 Batteries Required)
- APC POWERCELL PERSONAL POWERCELL (1 Battery Required)
- APC POWERSHIELD CP15U48D (1 Battery Required)
- APC POWERSHIELD CP24U12D (1 Battery Required)
- APC POWERSHIELD CP36U52 (1 Battery Required)
- APC PRO 250 (2 Batteries Required)
- APC Professional Power Cell (2 Batteries Required)
- APC RackMount 600 (2 Batteries Required)
- APC RBK600 (2 Batteries Required)
- APC RVC12 (2 Batteries Required)
- APC SMART-UPS 1000 RACK EXTENDED (4 Batteries Required)
- APC SMART-UPS 1000VA USB and SER (SUA1000RMUS) (4 Batteries Required)
- APC SMART-UPS 1400RM2U (4 Batteries Required)
- APC SMART-UPS 1400RM3U (SU1400RMNET) (4 Batteries Required)
- APC SMART-UPS 1400RM (4 Batteries Required)
- APC SMART-UPS 1400RM Black (SU1400RMBX120) (4 Batteries Required)
- APC SMART-UPS 1400RMNET (4 Batteries Required)
- APC SMART-UPS 1400RM (SU1400RM) (4 Batteries Required)
- APC SMART-UPS 1400VARM2U (SU1400R2BX120) (4 Batteries Required)
- APC SMART-UPS 1400VARM2U (SU1400R2X122) (4 Batteries Required)
- APC SMART-UPS 1400VARM2U (SU1400RM2U) (4 Batteries Required)
- APC SMART-UPS 1400VARM2U (SU1400RM2UX93) (4 Batteries Required)
- APC SMART-UPS 1400VARM3U (SU1400RMX106) (4 Batteries Required)
- APC SMART-UPS 1400VARM3U (SU1400RMX176) (4 Batteries Required)
- APC SMART-UPS 1500VARM2U (SUA1500R2X122) (4 Batteries Required)
- APC SMART-UPS 1500VARM2U (SUA1500R2X93) (4 Batteries Required)
- APC SMART-UPS 1500VA USB and SER (SUA1500RM2U) (4 Batteries Required)
- APC SMART-UPS 1500VA USB RM (DLA1500RM2U) (4 Batteries Required)
- APC SMART-UPS 2200RM3U (8 Batteries Required)
- APC SMART-UPS 2200RM3U (SU2200R3X106) (8 Batteries Required)
- APC SMART-UPS 2200VA RM3U (SU2200R2X167) (8 Batteries Required)
- APC SMART-UPS 2200VA RM3U (SU2200R3X147) (8 Batteries Required)
- APC SMART-UPS 2200VA RM3U (SU2200R3X152) (8 Batteries Required)
- APC SMART-UPS 2200VA RM3U (SU2200RM3U) (8 Batteries Required)
- APC SMART-UPS 2200VA USB and SER (SUA2200RM2U) (8 Batteries Required)
- APC SMART-UPS 2200VA USB and SER (SUA2200RMUS) (8 Batteries Required)
- APC SMART-UPS 2200VA USB RM (DLA2200RM2U) (8 Batteries Required)
- APC SMART-UPS 2500VA USB and SER (SUA1500RMUS) (4 Batteries Required)
- APC SMART-UPS 3000VA RM3U 120V (APC3RA) (8 Batteries Required)
- APC SMART-UPS 3000VA RM3U (SU3000R3BX120) (8 Batteries Required)
- APC SMART-UPS 3000VA RM3U (SU3000RM3U) (8 Batteries Required)
- APC SMART-UPS 3000VA RM3U (SU3000RMT3U) (8 Batteries Required)
- APC SMART-UPS 3000VA RM3U (SU3000RMTX136) (8 Batteries Required)
- APC SMART-UPS 3000VA RM3UW (SU3000R3X145) (8 Batteries Required)
- APC SMART-UPS 3000VA USB and SER (SUA3000RM2U) (8 Batteries Required)
- APC SMART-UPS 3000VA USB and SER (SUA3000RMT2U) (8 Batteries Required)
- APC SMART-UPS 3000VA USB and SER (SUA3000RMUS) (8 Batteries Required)
- APC SMART-UPS 3000VA USB RM2U (SUA3000R2X145) (8 Batteries Required)
- APC SMART-UPS 3000VA USB RM (DLA3000RM2U) (8 Batteries Required)
- APC SMART-UPS 3000VA USB RM (DLA3000RMT2U) (8 Batteries Required)
- APC SMART-UPS 3000VA USB (SUA3000R2X180) (8 Batteries Required)
- APC SMART-UPS 330 (AP330) (1 Battery Required)
- APC SMART-UPS 330XT+ (AP330XT+) (1 Battery Required)
- APC SMART-UPS 360 (AP360) (1 Battery Required)
- APC SMART-UPS 360SX (1 Battery Required)
- APC SMART-UPS 360SX (AP360SX) (1 Battery Required)
- APC SMART-UPS 420 (1 Battery Required)
- APC SMART-UPS 420VA (SU420NET) (1 Battery Required)
- APC SMART-UPS 420VA (SUVS420) (1 Battery Required)
- APC SMART-UPS 450 (2 Batteries Required)
- APC SMART-UPS 450 NET (SU450NET) (2 Batteries Required)
- APC SMART-UPS 450 (SU450) (2 Batteries Required)
- APC SMART-UPS 5000RMXLT5U (8 Batteries Required)
- APC SMART-UPS 5000VA 208V (SU5000T) (8 Batteries Required)
- APC SMART-UPS 5000VA 208V (SU5000TX168) (8 Batteries Required)
- APC SMART-UPS 5000VA RM5U (SU5000R5TBX120) (8 Batteries Required)
- APC SMART-UPS 5000VA RM5U (SU5000RMT5U) (8 Batteries Required)
- APC SMART-UPS 5000VA RM7U (SU5000R5T-TF3) (8 Batteries Required)
- APC SMART-UPS 5000VA RM7U (SU5000R5XLTFMR) (8 Batteries Required)
- APC SMART-UPS 5000VA RM7U (SU5000RMT5UXFMR) (8 Batteries Required)
- APC SMART-UPS 5000VA RM (DL5000RMT5U) (8 Batteries Required)
- APC SMART-UPS 5000VA w/Transformer (SU5000TXFMR) (8 Batteries Required)
- APC SMART-UPS 600 (2 Batteries Required)
- APC SMART-UPS 600 (AP600) (2 Batteries Required)
- APC SMART-UPS 600LS (2 Batteries Required)
- APC SMART-UPS 700 (2 Batteries Required)
- APC SMART-UPS 700RM3U (SU700RM) (2 Batteries Required)
- APC SMART-UPS 700VA Black (SU700BX120) (2 Batteries Required)
- APC SMART-UPS 700VA (DL700) (2 Batteries Required)
- APC SMART-UPS 700VA NAFTA (SU700US) (2 Batteries Required)
- APC SMART-UPS 700VA RM2U (SU700R2BX120) (2 Batteries Required)
- APC SMART-UPS 700VARM2U (SU700RM2U) (2 Batteries Required)
- APC SMART-UPS 700VA RM3U (SU700RMNET) (2 Batteries Required)
- APC SMART-UPS 700VA Ship (SU700X93) (2 Batteries Required)
- APC SMART-UPS 700VA (SU700NET) (2 Batteries Required)
- APC SMART-UPS 750VA USB and SER (SUA750RM2U) (2 Batteries Required)
- APC SMART-UPS Dell Smart UPS 2200VA USB RM (DLA2200RM2U) (8 Batteries Required)
- APC SMART-UPS Dell Smart UPS 3000VAUSBRM (DLA3000RMT2U) (8 Batteries Required)
- APC SMART-UPS Dell Smart UPS 5000VA RM (DL5000RMT5U) (8 Batteries Required)
- APC SMART-UPS DL700RMT5SU (2 Batteries Required)
- APC SMART-UPS HP Smart UPS 3000VA RM3U 208V (APC3TA) (8 Batteries Required)
- APC SMART-UPS IAXSURT2KIP10 (4 Batteries Required)
- APC SMART-UPS RM AP9621 (8 Batteries Required)
- APC SMART-UPS RM SU1400RM (4 Batteries Required)
- APC SMART-UPS RM SU1400RMBX120(34) (4 Batteries Required)
- APC SMART-UPS RM SU1400RM NET (4 Batteries Required)
- APC SMART-UPS RM SU1400RMX106 (4 Batteries Required)
- APC SMART-UPS RM SU1400RMX176 (4 Batteries Required)
- APC SMART-UPS RM SU1400RMX93 (4 Batteries Required)
- APC SMART-UPS RM SU1500RMX155 (4 Batteries Required)
- APC SMART-UPS RM SU1500RMXLX157 (4 Batteries Required)
- APC SMART-UPS RM SU2000R3X155 (8 Batteries Required)
- APC SMART-UPS RM SU2000RMXLX157 (8 Batteries Required)
- APC SMART-UPS RM SU2200R3BX120 (8 Batteries Required)
- APC SMART-UPS RM SU2200R3X106 (8 Batteries Required)
- APC SMART-UPS RM SU2200R3X147 (8 Batteries Required)
- APC SMART-UPS RM SU2200R3X152 (8 Batteries Required)
- APC SMART-UPS RM SU2200R3X167 (8 Batteries Required)
- APC SMART-UPS RM SU2200RM3U (8 Batteries Required)
- APC SMART-UPS RM SU2200RMXL3U (8 Batteries Required)
- APC SMART-UPS RM SU3000R3BX120 (8 Batteries Required)
- APC SMART-UPS RM SU3000R3X145 (8 Batteries Required)
- APC SMART-UPS RM SU3000RM3U (8 Batteries Required)
- APC SMART-UPS RM SU3000RMT3U (8 Batteries Required)
- APC SMART-UPS RM SU3000RMTX136 (8 Batteries Required)
- APC SMART-UPS RM SU5000R5TBX120 (8 Batteries Required)
- APC SMART-UPS RM SU5000R5XLTXFMR (16 Batteries Required)
- APC SMART-UPS RM SU5000RMT5U (16 Batteries Required)
- APC SMART-UPS RM SU5000RMT5UXFMR (16 Batteries Required)
- APC SMART-UPS RM SU5000RMTSU (8 Batteries Required)
- APC SMART-UPS RM SU5000RMXLT5U (16 Batteries Required)
- APC SMART-UPS RM SU700RM (2 Batteries Required)
- APC SMART-UPS RM SU700RM NET (2 Batteries Required)
- APC SMART-UPS SC 420VA (SC420) (1 Battery Required)
- APC SMART-UPS SL1400VARM3U (SU1400RMXL3U) (4 Batteries Required)
- APC SMART-UPS SMART 1000VARM2U (SU1000R2BX120) (4 Batteries Required)
- APC SMART-UPS SMART 1000VARM2U (SU1000RM2U) (4 Batteries Required)
- APC SMART-UPS SMART 1000VA USB and SER (SUA1000) (2 Batteries Required)
- APC SMART-UPS SMART 1000VA USB and SER (SUA1000RM2U) (4 Batteries Required)
- APC SMART-UPS SMART1000VA USB and SER (SUA1000US (2 Batteries Required)
- APC SMART-UPS SMART 1000XLI (4 Batteries Required)
- APC SMART-UPS SMART SC1000VA (SC1000) (2 Batteries Required)
- APC SMART-UPS SMART XL1000VA USB (SUA1000XL) (2 Batteries Required)
- APC SMART-UPS SP500DR (1 Battery Required)
- APC SMART-UPS SU1000RM2U (4 Batteries Required)
- APC SMART-UPS SU1400RMNET (4 Batteries Required)
- APC SMART-UPS SU1400RM (RACK) (4 Batteries Required)
- APC SMART-UPS SU1400RMXLIB3U (4 Batteries Required)
- APC SMART-UPS SU2200RMXL13U (8 Batteries Required)
- APC SMART-UPS SU24R2XLBP (8 Batteries Required)
- APC SMART-UPS SU24RMXLBP2U (8 Batteries Required)
- APC SMART-UPS SU3000RMXL13U (8 Batteries Required)
- APC SMART-UPS SU420 NET (1 Battery Required)
- APC SMART-UPS SU420VS (1 Battery Required)
- APC SMART-UPS SU450 (2 Batteries Required)
- APC SMART-UPS SU450 NET (2 Batteries Required)
- APC SMART-UPS SU48R3XLBP (8 Batteries Required)
- APC SMART-UPS SU48RMXLBP3U (8 Batteries Required)
- APC SMART-UPS SU5000R5TBX114 (8 Batteries Required)
- APC SMART-UPS SU5000R5TBX135 (8 Batteries Required)
- APC SMART-UPS SU5000R5TBXFMR (8 Batteries Required)
- APC SMART-UPS SU5000R5XLT-TF3 (8 Batteries Required)
- APC SMART-UPS SU5000R5XLT-TF5 (8 Batteries Required)
- APC SMART-UPS SU5000RMT5U (8 Batteries Required)
- APC SMART-UPS SU5000RMTXFMR (8 Batteries Required)
- APC SMART-UPS SU5000T (8 Batteries Required)
- APC SMART-UPS SU5000TX168 (8 Batteries Required)
- APC SMART-UPS SU5000TXFMR (8 Batteries Required)
- APC SMART-UPS SU600 (2 Batteries Required)
- APC SMART-UPS SU700 (2 Batteries Required)
- APC SMART-UPS SU700BX120 (2 Batteries Required)
- APC SMART-UPS SU700NET (2 Batteries Required)
- APC SMART-UPS SU700RMNET (2 Batteries Required)
- APC SMART-UPS SU700X167 (2 Batteries Required)
- APC SMART-UPS SUA1500R2X138 (4 Batteries Required)
- APC SMART-UPS SUO2000XLI (4 Batteries Required)
- APC SMART-UPS SUOL1000XLI (4 Batteries Required)
- APC SMART-UPS SURT2000RMXLI (4 Batteries Required)
- APC SMART-UPS SURT2000XLI (4 Batteries Required)
- APC SMART-UPS SUVS420 (1 Battery Required)
- APC SMART-UPS XL1400VARM 3U (SU1400RMXLB3U) (4 Batteries Required)
- APC SMART-UPS XL2200VA RM3U (SU2200RML3U) (8 Batteries Required)
- APC SMART-UPS XL3000VA RM3U (SU3000RMXL3U) (8 Batteries Required)
- APC UPS200 (2 Batteries Required)
- APC UPS300 (2 Batteries Required)
- APC UPS370CI (2 Batteries Required)
- APC UpStart350 (2 Batteries Required)
- APC UXBP48M (2 Batteries Required)
- Belkin F6C350-USB (1 Battery Required)
- Belkin F6C425-SER (1 Battery Required)
- Belkin F6C500USB (1 Battery Required)
- Belkin F6C800-UNV (1 Battery Required)
- Belkin F6H650 (1 Battery Required)
- Belkin PRO F6C425 (1 Battery Required)
- Belkin PRO F6C525 (1 Battery Required)
- Belkin PRO F6C625 (1 Battery Required)
- Belkin Pro F6C650 (1 Battery Required)
- Belkin PRO F6C700 (2 Batteries Required)
- Belkin Pro Gold F6C250-USB (1 Battery Required)
- Belkin PRO GOLD F6C350-USB (1 Battery Required)
- Belkin PRO GOLD F6C425-SER (1 Battery Required)
- Belkin Pro Gold F6C500-USB (1 Battery Required)
- Belkin Pro Net UPS F6C700 (2 Batteries Required)
- Best Power 280 UPS (1 Battery Required)
- Best Power 420 UPS (1 Battery Required)
- Best Power BEST LI-660VA (2 Batteries Required)
- Best Power FERRUPS Blackout Buster (1 Battery Required)
- Best Power FORTRESS 1422 BTG-0303 (4 Batteries Required)
- Best Power FORTRESS 750 BAT-0062 (2 Batteries Required)
- Best Power Fortress II LI 1020 BTG-0302 (3 Batteries Required)
- Best Power Fortress II LI 1420 BTG-0303 (4 Batteries Required)
- Best Power Fortress II LI 520 BTG-0301 (2 Batteries Required)
- Best Power Fortress II LI 720 BTG-0301 (2 Batteries Required)
- Best Power FORTRESS LI 1050 (3 Batteries Required)
- Best Power FORTRESS LI 1425 BAT-0062 (4 Batteries Required)
- Best Power Fortress LI 520 BAT-0062 (2 Batteries Required)
- Best Power Fortress LI 660 BAT-0062 (2 Batteries Required)
- Best Power Fortress LI 675 BAT-0062 (2 Batteries Required)
- Best Power Fortress LI 720 BAT-0062 (2 Batteries Required)
- Best Power Fortress Rack Mount LI 720 BAT-0370 (2 Batteries Required)
- Best Power PATRIOT 0305-0250U (1 Battery Required)
- Best Power PATRIOT 0305-0425U (1 Battery Required)
- Best Power PATRIOT 420 UPS (1 Battery Required)
- Best Power PATRIOT Blackout Buster (1 Battery Required)
- Best Power PATRIOT SMT280 (1 Battery Required)
- Best Power PATRIOT SMT420 (1 Battery Required)
- Best Power PATRIOT SPI1250 (1 Battery Required)
- Best Power PATRIOT SPI1400 (1 Battery Required)
- Best Power PATRIOT SPS450 (1 Battery Required)
- Best Power PATRIOT SPS850 (2 Batteries Required)
- Best Technologies BTG-0301 (2 Batteries Required)
- Best Technologies BTG-0302 (3 Batteries Required)
- Best Technologies BTG-0303 (4 Batteries Required)
- Best Technologies Fortress 1050 (1 Battery Required)
- Best Technologies Fortress 1425 (1 Battery Required)
- Best Technologies Fortress II LI 660VA (8 Batteries Required)
- Best Technologies Fortress LI 1420 (BTG-0303) (4 Batteries Required)
- Best Technologies Fortress LI 660 (2 Batteries Required)
- Best Technologies Fortress LI 750 (BAT-0062) (2 Batteries Required)
- Best Technologies Fortress Rack Mount LI 1050 (3 Batteries Required)
- Best Technologies Fortress Rack Mount LI 1422 (4 Batteries Required)
- Best Technologies Fortress Rack Mount LI 1425 (4 Batteries Required)
- Best Technologies Fortress Rack Mount LI 750 (2 Batteries Required)
- Best Technologies Fortress Rack Mount LI 750 (BAT-0062) (2 Batteries Required)
- Best Technologies LCR12V6.5BP1 (1 Battery Required)
- Best Technologies LI 520 BTG-0301 (2 Batteries Required)
- Best Technologies LI660 (1 Battery Required)
- Best Technologies LI660VA (1 Battery Required)
- Best Technologies LI 720 BTG-0301 (2 Batteries Required)
- Best Technologies MD1.5KVA (1 Battery Required)
- Best Technologies MD2KVA (1 Battery Required)
- Best Technologies PATRIOT 280 (1 Battery Required)
- Best Technologies PATRIOT 600 (1 Battery Required)
- Best Technologies SPS450 (1 Battery Required)
- Best Technologies SPS450VA (1 Battery Required)
- Cabac UPS1000DV2 (2 Batteries Required)
- Cabac UPS650DV2 (1 Battery Required)
- Clary 1000 On Guard (4 Batteries Required)
- Clary 1800VA (1 Battery Required)
- Clary l800VA (4 Batteries Required)
- Clary UPS11251GR (1 Battery Required)
- Clary UPS1125K1G (1 Battery Required)
- Clary UPS1125K1GSBS (1 Battery Required)
- Clary UPS1125K1GSBSR (1 Battery Required)
- Clary UPS1-1.5K-1G (5 Batteries Required)
- Clary UPS115K1GR (1 Battery Required)
- Clary UPS115K1GSBS (1 Battery Required)
- Clary UPS115K1GSBSR (1 Battery Required)
- Clary UPS11K1G (5 Batteries Required)
- Clary UPS11K1GR (1 Battery Required)
- Clary UPS11K1GSBSR (1 Battery Required)
- Clary UPS1400VA1GSL (1 Battery Required)
- Clary UPS1800VA1G (1 Battery Required)
- Clary UPS1800VA1GR (1 Battery Required)
- Clary UPS1800VA1GSBS (1 Battery Required)
- Clary UPS1800VA1GSBSR (1 Battery Required)
- Clary UPS23K1GSBSR (1 Battery Required)
- Clary UPS800VA1GSBS (1 Battery Required)
- Compaq R1500 (4 Batteries Required)
- Compaq UP6003-2 (10 Batteries Required)
- Cyber Power BPE240V30ART3U (20 Batteries required)
- Cyber Power BR650ELCD (1 battery required)
- Cyber Power BR700ELCD (1 battery required)
- Cyber Power CP1300EPFCLCD (2 Batteries required)
- Cyber Power CPS1250AVR (2 Batteries Required)
- Cyber Power CPS500SL (1 Battery Required)
- Cyber Power CPS575SL (1 Battery Required)
- Cyber Power CPS585AVR (1 Battery Required)
- Cyber Power CPS625AVR (1 Battery Required)
- Cyber Power CPS650SL (1 Battery Required)
- Cyber Power CPS700AVR (1 Battery Required)
- Cyber Power CPS900AVR (2 Batteries Required)
- Cyber Power CS24U12V (1 Battery Required)
- Cyber Power OFFICE POWER 1000AVR (2 Batteries Required)
- Cyber Power OFFICE POWER 1500AVR (4 Batteries Required)
- Cyber Power OFFICE POWER 900AVR (2 Batteries Required)
- Cyber Power OFFICE POWER BA-825AVR (1 Battery Required)
- Cyber Power OL6000ERT3UDM (20 Batteries required)
- Cyber Power OL6000ERT3UP (20 Batteries required)
- Cyber Power OLS1000E (3 Batteries required)
- Cyber Power OLS2000E (6 Batteries required)
- Cyber Power OLS6000E (20 Batteries required)
- Cyber Power PR1000ELCDRT1U (4 Batteries required)
- Cyber Power PR1000ELCDRT2U (4 Batteries required)
- Cyber Power PR1000ELCDRTXL2U (4 Batteries required)
- Cyber Power PR1500ELCDRT2U (4 Batteries required)
- Cyber Power PR750ELCD (2 Batteries required)
- Cyber Power PR750ELCDRT1U (4 Batteries required)
- Cyber Power VALUE1200ELCD (2 Batteries required)
- Cyber Power VALUE600EI-AU (1 battery required)
- Data General C4-775A (2 batteries Required)
- Data General L600 (2 Batteries Required)
- Data Shield ST 360 (1 Battery Required)
- Data Shield T2+200 (2 Batteries Required)
- Deltec PRA600 (2 Batteries Required)
- Deltech PRA 400 (2 Batteries Required)
- Deltech PRB220 (1 Battery Required)
- Deltech PRB300 (1 Battery Required)
- Deltech PRM450 (1 Battery Required)
- Deltech RS-21 (10 Batteries Required)
- Deltech RS-32 (10 Batteries Required)
- Easy Options 400VA (1 Battery Required)
- EFI LANGUARD 500 (2 Batteries Required)
- EFI LANGUARD 600 (2 Batteries Required)
- EFI LANGUARD 675 (1 Battery Required)
- Emerson 200 (2 Batteries Required)
- Emerson AU-750-60 (3 Batteries Required)
- EPD Grizzly 300VRS (2 Batteries Required)
- EPD Grizzly 500 (4 Batteries Required)
- EPD Grizzly VRS500 (4 Batteries Required)
- EPE INTEGRITY IS-1122/11 (6 Batteries Required)
- Fenex FX2002 (2 Batteries Required)
- Fenton M1000 (3 Batteries Required)
- Fenton M2000 (6 Batteries Required)
- Fenton M3000 (8 Batteries Required)
- Fenton Power On H010K (1 Battery Required)
- Fenton Power On H3500 (1 Battery Required)
- Fenton Power On H4000 (1 Battery Required)
- Fenton Power On H5500 (1 Battery Required)
- Fenton Power On H6000 (1 Battery Required)
- Fenton Power On H8000 (1 Battery Required)
- Fenton Power Pal L425 (1 Battery Required)
- Fenton Power Pure M1000 (1 Battery Required)
- Fenton Power Pure M2000 (1 Battery Required)
- Fenton PS60 (2 Batteries Required)
- GE GT1000T (3 Batteries Required)
- GE GT1500T (6 Batteries Required)
- GE GT2000T (6 Batteries Required)
- GE VH1500 (6 Batteries Required)
- GE VH700 (3 Batteries Required)
- General Power GPS5006 (5 Batteries Required)
- Hewlett Packard HP 1000 (2 Batteries Required)
- Hewlett Packard PowerWise 1000 (4 Batteries Required)
- Hewlett Packard PowerWise 1250 (4 Batteries Required)
- Hewlett Packard PowerWise 2100 (1 Battery Required)
- Hewlett Packard Powerwise L600 (2 Batteries Required)
- Hewlett Packard PowerWise L900 (2 Batteries Required)
- Intellipower IQ 1100RM (3 Batteries Required)
- Invivo Research Inc 3150M MRI Patient Monitor (four batteries required)
- Leadman UPS (1 Battery Required)
- Leadman UPS 300 (2 Batteries Required)
- Leadman UPS 500 (2 Batteries Required)
- Legend UPS1000DLV2 (2 Batteries Required)
- Legend UPS1700DLV2 (4 Batteries Required)
- Legend UPS650DLV2 (1 Battery Required)
- Liebert GXT2-1000RT230 (4 Batteries Required)
- Liebert GXT2-1500RT230 (4 Batteries Required)
- Liebert GXT2-700RT230 (4 Batteries Required)
- Liebert PowerSure Interactive PS 1000MT (3 Batteries Required)
- Liebert PowerSure Interactive PS1000RM (3 Batteries Required)
- Liebert PowerSure Interactive PS 1400MT (4 Batteries Required)
- Liebert PowerSure Interactive PS 1400RM (4 Batteries Required)
- Liebert PowerSure Interactive PS 700MT (2 Batteries Required)
- Liebert PowerSure Interactive PS 700RM (2 Batteries Required)
- Liebert PowerSure Personal PSP 500 (1 Battery Required)
- Liebert PowerSure Proactive PSA 350 (1 Battery Required)
- Liebert PowerSure Proactive PSA 470 (1 Battery Required)
- Liebert Up Station D 600VA (2 Batteries Required)
- Liebert Up Station D PSP 500 (1 Battery Required)
- Liebert Up Station D S1000MT (3 Batteries Required)
- Liebert Up Station D S1400MT (4 Batteries Required)
- Liebert Up Station GXT 1000MT-120 (3 Batteries Required)
- Liebert Up Station GXT 1000RT-120 (3 Batteries Required)
- Liebert Up Station GXT 1000RTE-120 (6 Batteries Required)
- Liebert Up Station GXT 1500RT-120 (4 Batteries Required)
- Liebert Up Station GXT 2000RT-120 (8 Batteries Required)
- Liebert Up Station GXT 2100RT-60 (8 Batteries Required)
- Liebert Up Station GXT 3000RT-120 (8 Batteries Required)
- Liebert Up Station GXT 700MT-120 (2 Batteries Required)
- Merich 350 (2 Batteries Required)
- Merich 400 (2 Batteries Required)
- Merich 450C (4 Batteries Required)
- Merich 850C (4 Batteries Required)
- Merich M1200 (6 Batteries Required)
- Merich UPS400 (2 Batteries Required)
- MGE ES8+ (2 Batteries Required)
- MGE ESV11 (3 Batteries Required)
- MGE ESV13+ (4 Batteries Required)
- MGE ESV14+ (4 Batteries Required)
- MGE ESV8 (2 Batteries Required)
- MGE Pulsar EL7 (2 Batteries Required)
- NCR UPS 4071-0600-7194 (2 Batteries Required)
- Oneac 436-008 (4 Batteries Required)
- Oneac 436-014 (4 Batteries Required)
- Oneac ON1300 (6 Batteries Required)
- Oneac ON2000 (8 Batteries Required)
- Oneac ON400XR (2 Batteries Required)
- Oneac ON600 (2 Batteries Required)
- Oneac ONe200 (1 Battery Required)
- Oneac ONe200X (2 Batteries Required)
- Oneac ONe300 (1 Battery Required)
- Oneac ONe300X (2 Batteries Required)
- Oneac ONe400D (2 Batteries Required)
- Oneac ONm300 (1 Battery Required)
- Oneac ONm600X (2 Batteries Required)
- Oneac Series E ON1300 (6 Batteries Required)
- Oneac Series E ON2000 (8 Batteries Required
- Oneac Series E ON900 (4 Batteries Required)
- Oneac Series E ONe300D (2 Batteries Required)
- Oneac Series E ONe400D (2 Batteries Required)
- Oneac UP-1105 (4 Batteries Required)
- Opti 1300 (1 Battery Required)
- Opti 1BP107 (1 Battery Required)
- Opti 1BP207 (1 Battery Required)
- Opti 1BP407 (1 Battery Required)
- Opti 1BP607 (1 Battery Required)
- Opti 2000 (1 Battery Required)
- Opti 280E (1 Battery Required)
- Opti 280 ES (1 Battery Required)
- Opti 350059 (1 Battery Required)
- Opti 350VS (1 Battery Required)
- Opti 400XR (1 Battery Required)
- Opti 420E (1 Battery Required)
- Opti 500VS (1 Battery Required)
- Opti 600 (1 Battery Required)
- Opti 800PS (2 Batteries Required)
- Opti 900 (1 Battery Required)
- Opti BT (1 Battery Required)
- Opti BT2PAC (1 Battery Required)
- Opti BT4PAC (1 Battery Required)
- Opti ON1300 (1 Battery Required)
- Opti ON1300XRA (1 Battery Required)
- Opti ON2000 (1 Battery Required)
- Opti ON2000XRA (1 Battery Required)
- Opti ON400XR (1 Battery Required)
- Opti ON400XRA (1 Battery Required)
- Opti ON600 (1 Battery Required)
- Opti ON600XRA (1 Battery Required)
- Opti ON900 (1 Battery Required)
- Opti ON900XRA (1 Battery Required)
- Opti ON910 (1 Battery Required)
- Opti ONEBP107 (1 Battery Required)
- Opti ONEBP207 (1 Battery Required)
- Opti ONEBP407 (1 Battery Required)
- Opti ONEBP607 (1 Battery Required)
- Opti UP1103 (1 Battery Required)
- Parasystems MINUTEMAN A300 (1 Battery Required)
- Parasystems MINUTEMAN A300/2 (1 Battery Required)
- Parasystems MINUTEMAN A300L (1 Battery Required)
- Parasystems MINUTEMAN A425 (1 Battery Required)
- Parasystems MINUTEMAN A425/2 (1 Battery Required)
- Parasystems MINUTEMAN A750/2 (2 Batteries Required)
- Parasystems MINUTEMAN A750 (2 Batteries Required)
- Parasystems MINUTEMAN Rack Mount PRO 1000R (4 Batteries Required)
- Parasystems MINUTEMAN Rack Mount PRO 1400R (4 Batteries Required)
- Parasystems MINUTEMAN Rack Mount PRO 700R (2 Batteries Required)
- Para Systems A750 (2 Batteries Required)
- Para Systems MINUTEMAN 1000 (7 Batteries Required)
- Para Systems MINUTEMAN 250 (1 Battery Required)
- Para Systems MINUTEMAN 300CP (16 Batteries Required)
- Para Systems MINUTEMAN 300SS (2 Batteries Required)
- Para Systems MINUTEMAN 450 (1 Battery Required)
- Para Systems MINUTEMAN 600 (1 Battery Required)
- Para Systems MINUTEMAN 60022 (4 Batteries Required)
- Para Systems MINUTEMAN 600SS (4 Batteries Required)
- Para Systems MINUTEMAN 900SS (8 Batteries Required)
- Para Systems MINUTEMAN AT650 (1 Battery Required)
- PCM Powercom KIN-1000AP (2 Batteries Required)
- PCM Powercom KIN-625AP (1 Battery Required)
- Powerware 5155 (2 Batteries Required)
- Powerware FX2002 (2 Batteries Required)
- Powerware PLUS 6 (20 Batteries Required)
- Powerware Powerware 9125-1000 (2 Batteries Required)
- Powerware Powerware 9125-1250 (4 Batteries Required)
- Powerware Powerware 9125-1500 (4 Batteries Required)
- Powerware Powerware 9125-2000 (4 Batteries Required)
- Powerware Powerware 9125-2500 (6 Batteries Required)
- Powerware Powerware 9125-3000 (6 Batteries Required)
- Powerware Powerware 9125-700 (2 Batteries Required)
- Powerware Powerware OneUPS (1 Battery Required)
- Powerware Powerware PW3110-250 (1 Battery Required)
- Powerware Powerware PW3110-425 (1 Battery Required)
- Powerware Powerware PW3115-300 (1 Battery Required)
- Powerware Powerware PW5105-450 (1 Battery Required)
- Powerware Powerware PW5115-750 (2 Batteries Required)
- Powerware Powerware PW5119-1500 (3 Batteries Required)
- Powerware/Exide Exide PW 3115-300 (1 Battery Required)
- Powerware/Exide Exide PW 5105-450 (1 Battery Required)
- Safe 650 (2 Batteries Required)
- Safe SM650 (2 Batteries Required)
- Scooter SPS500AT (6 Batteries Required)
- Sola 0510-0900U (4 Batteries Required)
- Sola 054-00210-0100-19 (600VA) (4 Batteries Required)
- Sola 2993638601 (1 Battery Required)
- Sola 310A (1 Battery Required)
- Sola 600VA (4 Batteries Required)
- Sola 900VA (1 Battery Required)
- Sola N900 (2 Batteries Required)
- Sola NETWORK UPS N900 (4 Batteries Required)
- Sola S24K2U48BAT (8 Batteries Required)
- Sola S31000 (3 Batteries Required)
- Sola S31000R (3 Batteries Required)
- Sola S314000 (4 Batteries Required)
- Sola S31400R (4 Batteries Required)
- Sola S32200R (8 Batteries Required)
- Sola S3700 (2 Batteries Required)
- Sola S3700R (2 Batteries Required)
- Sola S370 (2 Batteries Required)
- Sola S41000 (3 Batteries Required)
- Sola S41000TRM (3 Batteries Required)
- Sola S41500TRM (4 Batteries Required)
- Sola S4700 (2 Batteries Required)
- Sola S4K2U2000 (4 Batteries Required)
- Toshiba 1200 3 KVA (1 Battery Required)
- Toshiba 1200 5KVA (1 Battery Required)
- Toshiba 1200 Model 3 (1 Battery Required)
- Toshiba 1200 SER .5KVA (1 Battery Required)
- Toshiba 1400SE Plus (8 Batteries Required)
- Toshiba 5KVA 208 Vol (1 Battery Required)
- Toshiba 5KVA 240 Volt (1 Battery Required)
- Toshiba 750 (1 Battery Required)
- Toshiba ECB1U12030U (1 Battery Required)
- Toshiba PR00015P31 (1 Battery Required)
- Triad UPS600 (6 Batteries Required)
- Tripp Lite 360SX (2 Batteries Required)
- Tripp Lite 500 (1 Battery Required)
- Tripp Lite 600 (3 Batteries Required)
- Tripp Lite 850 (4 Batteries Required)
- Tripp Lite BC200-228B (1 Battery Required)
- Tripp Lite BC250 (1 Battery Required)
- Tripp Lite BC250A (3 Batteries Required)
- Tripp Lite BC300 Internet (2 Batteries Required)
- Tripp Lite BC325 (2 Batteries Required)
- Tripp Lite BC325A (2 Batteries Required)
- Tripp Lite BC3348 (1 Battery Required)
- Tripp Lite BC400INT (1 Battery Required)
- Tripp Lite BC400 LAN (3 Batteries Required)
- Tripp Lite BC400 Standby (1 Battery Required)
- Tripp Lite BC 420 (1 Battery Required)
- Tripp Lite BC420 (1 Battery Required)
- Tripp Lite BC450 (1 Battery Required)
- Tripp Lite BC 500 (1 Battery Required)
- Tripp Lite BC500LAN (1 Battery Required)
- Tripp Lite BC Internet 450 (1 Battery Required)
- Tripp Lite BC Internet 500 (1 Battery Required)
- Tripp Lite BC Internet 550 (1 Battery Required)
- Tripp Lite BC PERS 420 (1 Battery Required)
- Tripp Lite BC PERS 450 (1 Battery Required)
- Tripp Lite BC Personal 420 (1 Battery Required)
- Tripp Lite BC PRO 450 (1 Battery Required)
- Tripp Lite BC PRO600 (1 Battery Required)
- Tripp Lite BC PRO 850A (3 Batteries Required)
- Tripp Lite CP 350 (2 Batteries Required)
- Tripp Lite Datashield PC200A (2 Batteries Required)
- Tripp Lite Datashield T2+200 (2 Batteries Required)
- Tripp Lite Datashield T2+300 (2 Batteries Required)
- Tripp Lite Internet Office 500 (1 Battery Required)
- Tripp Lite MISC TMC CP350 (3 Batteries Required)
- Tripp Lite MPS 1500 (6 Batteries Required)
- Tripp Lite Office 500 (1 Battery Required)
- Tripp Lite OM1995 (1 Battery Required)
- Tripp Lite OMNI 2000A (6 Batteries Required)
- Tripp Lite OMNI 600B LAN (2 Batteries Required)
- Tripp Lite OMNI 850 (4 Batteries Required)
- Tripp Lite OMNI PRO Network Pro 450 (1 Battery Required)
- Tripp Lite OMNI SMART 450 (1 Battery Required)
- Tripp Lite PS6.0 (2 Batteries Required)
- Tripp Lite SMART 400 UPS(1 Battery Required)
- Tripp Lite SMART 450 (1 Battery Required)
- Tripp Lite SMART PRO Net 450 (1 Battery Required)
- Tripp Lite SMART Unison PS700 (2 Batteries Required)
- Tripp Lite TE1200 (1 Battery Required)
- Tripp Lite TE700 (1 Battery Required)
- Tripp Lite Unison MPS1200 (5 Batteries Required)
- Tripp Lite Unison MPS1200A (4 Batteries Required)
- Tripp Lite Unison PS6.0 (2 Batteries Required)
- Tripp Lite Unison PS6.0N (2 Batteries Required)
- Tripp Lite Unison PS8.0 (2 Batteries Required)
- Unison MPS1200 (5 Batteries Required)
- Unison MPS1200A (4 Batteries Required)
- Unison MPS1500 (6 Batteries Required)
- Unison PS60 (2 Batteries Required)
- Unison PS6 (2 Batteries Required)
- Unisys MPS1400 (4 Batteries Required)
- Unisys MPS2000 (8 Batteries Required)
- Unisys PS60 (2 Batteries Required)
- Unisys PS6.0 N (2 Batteries Required)
- Unisys PS700 (2 Batteries Required)
- Unisys PS8.0 (2 Batteries Required)
- Unisys PS8.0 N (2 Batteries Required)
- Upsonic CS 1000 (2 batteries required)
- Upsonic CS 2000 (4 batteries required)
- Upsonic CXR 1000 (4 batteries required)
- Upsonic CXR 2000 (8 batteries required)
- Upsonic DS 1000 (2 Batteries Required)
- Upsonic DS 600 (1 Battery Required)
- Upsonic ESLR 15 (16 batteries required)
- Upsonic ESLR 20 (16 batteries required)
- Upsonic ESLR 30 (16 batteries required)
- Upsonic ESLR 50 (16 batteries required)
- Upsonic ESLR 75 (16 batteries required)
- Upsonic ESRT 10 (2 batteries required)
- Upsonic ESRT 15 (3 batteries required)
- Upsonic ESRT 30 (6 batteries required)
- Upsonic EST 10 (2 batteries required)
- Upsonic EST 15 (3 batteries required)
- Upsonic IH 1000 (3 batteries required)
- Upsonic IH 2000 (6 batteries required)
- Upsonic IH 3000 (10 batteries required)
- Upsonic IH 5000 (16 batteries required)
- Upsonic IH 6000 (16 batteries required)
- Upsonic IP 6000 (20 batteries required)
- Upsonic IRT 1000 (3 batteries required)
- Upsonic IRT 2000 (6 batteries required)
- Upsonic IRT 3000 (8 batteries required)
- Upsonic IS 1000 (3 batteries required)
- Upsonic LAN 100 (4 Batteries Required)
- Upsonic LAN 150 (6 Batteries Required)
- Upsonic Might 35 (1 Battery Required)
- Upsonic PCM 140 (2 Batteries Required)
- Upsonic PCM 140VR (2 Batteries Required)
- Upsonic PCM 200 (2 Batteries Required)
- Upsonic PCM 200VR (2 Batteries Required)
- Upsonic PCM 35 (2 Batteries Required)
- Upsonic PCM 55 (2 Batteries Required)
- Upsonic PCM 55R (2 Batteries Required)
- Upsonic PC Mate 55 (2 Batteries Required)
- Upsonic PC Might 35 (1 Battery Required)
- Upsonic PC Might 55 (2 Batteries Required)
- Upsonic PrOffice 650 (1 battery required)
- Upsonic Station 140 (4 Batteries Required)
- Upsonic Station 200 (2 Batteries Required)
- Upsonic Station 28 (1 Battery Required)
- Upsonic Station 40 (2 Batteries Required)
- Upsonic Station 60 (2 Batteries Required)
- Upsonic System 100 (2 Batteries Required)
- Upsonic System 300 (2 Batteries Required)
- Upsonic System 60 (2 Batteries Required)
- Upsonic UPS 1250 (2 Batteries Required)
- Upsonic UPS 200 (2 Batteries Required)
- Upsonic UPS 600 (2 Batteries Required)
- Zapotek ATandT 515 (3 Batteries Required)
- Zapotek RX501N (1 Battery Required)
- Zapotek RX-501N (4 Batteries Required)
- Zapotek RX510N (4 Batteries Required)
- Zapotek RX510N (Sota SA1272F003) (1 Battery Required)
- Zapotek SA1272f003 (1 Battery Required)

Compatible With:	APC RBC12 (8 battery required)	APC RBC16 (4 battery required)	APC RBC5 (2 battery required)
	APC RBC17 (1 battery required)	APC RBC12 (2 battery required)	APC RBC15 (1 battery required)
	APC RBC2 (1 battery required)	APC RBC13 (2 battery required)	APC RBC16 (4 battery required)
	APC RBC22 (2 battery required)	APC RBC18 (8 battery required)	APC RBC18 (4 battery required)
	APC RBC23 (4 battery required)	APC RBC17 (8 battery required)	APC RBC18 (2 battery required)
	APC RBC24 (4 battery required)	APC RBC18 (1 battery required)	APC RBC12 (2 battery required)
	APC RBC25 (4 battery required)	APC RBC18 (2 battery required)	APC RBC8 (4 battery required)
	APC RBC26 (8 battery required)	APC RBC11 (1 battery required)	APC RBC9 (2 battery required)
	APC RBC27 (8 battery required)		
Comments			

This battery is specifically designed for standby use, ideal for security, fire panels and Uninterruptible Power Supply (UPS) use.
This model is not recommended for cyclic use.
The UP-VW1290PS is the wide terminal version fitted with Faston 250 (F2) spade terminals.
Former model : UP-RW1290PS, New model in Flame retardant case (UL94-V0 R). Replaces UP-RW1290PS
Replay Instruments is proud to be the official major distributor for Panasonic industrial batteries including Panasonic sealed lead acid (VRLA) batteries in Australia on behalf of Panasonic Storage Battery (Thailand) Co., Ltd. (PSBA)

Note 1 & NOTE FLAME RETARDANT CASING MODEL

This product's casing/housing is classed **NOTE 1** In simple terms, this means that the casing/housing is considered flame retardant in accordance with the plastics flammability standard.

Data Sheet	