



LC-R0612P1

Model No	LC-R0612P1
Selling Unit	EACH
Description	LC-R0612P1 Panasonic Sealed Lead Acid Battery
Application	Cyclic & Standby, UPS, Security, Alarm, Instrument, Test Equipment, Toy, Medical Equipment
Chemistry	Sealed Lead
Voltage	6V
Watt Hour	72Wh
Watts Per Cell	64W
Nominal Capacity	12Ah
Termination	F2, Faston 250 6.3mm (0.25") spade terminals
Width	50mm
Height	94mm
Length/Breadth/Depth	151mm
Weight	1950g
Outer Quantity	12

Suitable For:

Alpha Technologies 2000 (4 Batteries Required)	Hewlett Packard Powertrust (4 Batteries Required)	Tripp Lite BC500INT (2 Batteries Required)
APC 450AT (2 Batteries Required)	Liebert PowerSure Interactive PS 2200MT (8 Batteries Required)	Tripp Lite BC 500 Internet (2 Batteries Required)
APC 450AT+ (2 Batteries Required)	Liebert PowerSure Interactive PS 2200RM (8 Batteries Required)	Tripp Lite BC550 (1 Battery Required)
APC 520ES (2 Batteries Required)	Liebert Up Station D S2200MT (8 Batteries Required)	Tripp Lite BC600 (3 Batteries Required)
APC 550ES (2 Batteries Required)	Liebert Up Station D UD1400VA (6 Batteries Required)	Tripp Lite BC600A (3 Batteries Required)
APC 800RT (2 Batteries Required)	Oneac ON900 (4 Batteries Required)	Tripp Lite BC600B/230 (3 Batteries Required)
APC AP166 (2 Batteries Required)	Oneac ON900A (4 Batteries Required)	Tripp Lite BC600B (3 Batteries Required)
APC AP250 (3 Batteries Required)	Oneac Series E One2000 (2 Batteries Required)	Tripp Lite BC600BLAN (3 Batteries Required)
APC AP450 (2 Batteries Required)	Opti 1000 (1 Battery Required)	Tripp Lite BC600INT (3 Batteries Required)
APC AP520 (2 Batteries Required)	Opti 1000E (3 Batteries Required)	Tripp Lite BC600LAN (3 Batteries Required)
APC AP800 (4 Batteries Required)	Opti 1BP210 (1 Battery Required)	Tripp Lite BC600NOV (3 Batteries Required)
APC AP800RT (4 Batteries Required)	Opti ONEBP210 (1 Battery Required)	Tripp Lite BC675 Internet (1 Battery Required)
APC AP900 (4 Batteries Required)	Pacific Power VANGUARD (2 Batteries Required)	Tripp Lite BC675 PRO (1 Battery Required)
APC APC450 (2 Batteries Required)	Parasystems MINUTEMAN A1250/2 (4 Batteries Required)	Tripp Lite BC Internet 675 (2 Batteries Required)
APC BACK-UPS 450 (2 Batteries Required)	Parasystems MINUTEMAN A1250 (4 Batteries Required)	Tripp Lite BC PERS 500 (2 Batteries Required)
APC BACK-UPS 600 (2 Batteries Required)	Parasystems MINUTEMAN A2000 (6 Batteries Required)	Tripp Lite BC Personal 500 NEW (2 Batteries Required)
APC BACK-UPS 650 (BK650MC) (2 Batteries Required)	Parasystems MINUTEMAN A500/2 (2 Batteries Required)	Tripp Lite BC Personal 500 OLD (1 Battery Required)
APC BACK-UPS 900 (4 Batteries Required)	Parasystems MINUTEMAN A500 (2 Batteries Required)	Tripp Lite BC PRO 1050 (4 Batteries Required)
APC BACK-UPS BK450 (2 Batteries Required)	Parasystems MINUTEMAN A900/2 (4 Batteries Required)	Tripp Lite BC PRO 1400 (5 Batteries Required)
APC BACK-UPS BK520 (2 Batteries Required)	Parasystems MINUTEMAN A900 (4 Batteries Required)	Tripp Lite BC PRO 550 (2 Batteries Required)
APC BACK-UPS BK575C (2 Batteries Required)	Para Systems MINUTEMAN 500 (4 Batteries Required)	Tripp Lite BC PRO 675 (2 Batteries Required)
APC BACK-UPS BK600 (2 Batteries Required)	Para Systems MINUTEMAN 550 (4 Batteries Required)	Tripp Lite BC PRO 850 (3 Batteries Required)
APC BACK-UPS BK600C (2 Batteries Required)	Powerware PowerWare 2000 (20 Batteries Required)	Tripp Lite BC PRO Internet 1050 (1 Battery Required)
APC BACK-UPS BK900 (4 Batteries Required)	Powerware Powerware PW3115-650 (2 Batteries Required)	Tripp Lite BC PRO Internet 1050 (1 Battery Required)
APC NS2200RM3U (2 Batteries Required)	Powerware/Exide Exide PW 3115-650 (2 Batteries Required)	Tripp Lite Datsshield T2+520 (2 Batteries Required)
APC NS3000RM3U (2 Batteries Required)	Safe 1200 (8 Batteries Required)	Tripp Lite Internet Office 700 (2 Batteries Required)
APC NS3000RM3U (2 Batteries Required)	Safe 1200A (8 Batteries Required)	Tripp Lite MISC TMC TE300 (3 Batteries Required)
APC PCNET (2 Batteries Required)	Safe 250 (2 Batteries Required)	Tripp Lite MISC TMC TE300 Later (1 Battery Required)
APC POWERCELL NETWORK POWERCELL (2 Batteries Required)	Safe 400 (4 Batteries Required)	Tripp Lite MISC TMC TE700A (5 Batteries Required)
APC RBK520 (2 Batteries Required)	Safe 400A (4 Batteries Required)	Tripp Lite OMNI 500 LAN (2 Batteries Required)
APC RBK900 (2 Batteries Required)	Safe 425 (4 Batteries Required)	Tripp Lite OMNI 600/230 (2 Batteries Required)
APC SMART-UPS 450 (AP450) (2 Batteries Required)	Safe 425A (4 Batteries Required)	Tripp Lite OMNI 675 (2 Batteries Required)
APC SMART-UPS 520 (AP520) (2 Batteries Required)	Safe 500 (4 Batteries Required)	Tripp Lite OMNI PRO 675 (2 Batteries Required)
APC SMART-UPS 750VA (DLA750) (2 Batteries Required)	Safe 500A (4 Batteries Required)	Tripp Lite OMNI PRO 850 (3 Batteries Required)
APC SMART-UPS 750VA USB and SER (SUA750RM1U) (4 Batteries Required)	Safe FES200A (4 Batteries Required)	Tripp Lite OMNI PRO Network Pro 1050 (4 Batteries Required)
APC SMART-UPS 750VA USB (SUA750) (2 Batteries Required)	Safe SM1400 (8 Batteries Required)	Tripp Lite OMNI PRO Network Pro 1400 (5 Batteries Required)
APC SMART-UPS 900 (4 Batteries Required)	Safe SM800 (4 Batteries Required)	Tripp Lite OMNI PRO Network Pro 675 (2 Batteries Required)
APC SMART-UPS SU900 (4 Batteries Required)	Safe SPS1000 (8 Batteries Required)	Tripp Lite OMNI PRO Network Pro 850 (3 Batteries Required)
APC UPS520EST (2 Batteries Required)	Safe STS200-117 (1 Battery Required)	Tripp Lite OMNI SMART 1050 (4 Batteries Required)
APS 6001 (2 Batteries Required)	Sola 056-00208-000-26 (450VA) (2 Batteries Required)	Tripp Lite OMNI SMART 1400 (5 Batteries Required)
Best Power Fortress LI 1020 BAT-0063 (2 Batteries Required)	Sola 290352210 (1 Battery Required)	Tripp Lite OMNI SMART 650 (3 Batteries Required)
Best Power FORTRESS LI 1800 BAT-0063 (8 Batteries Required)	Sola 32200 (8 Batteries Required)	Tripp Lite OMNI SMART 675 (2 Batteries Required)
Best Power FORTRESS LI 2250 BAT-0063 (8 Batteries Required)	Sola 325 1000VA (3 Batteries Required)	Tripp Lite OMNI SMART 725 (1 Battery Required)
Best Power Fortress LI 750 BAT-0063 (2 Batteries Required)	Sola 400VA (2 Batteries Required)	Tripp Lite OMNI SMART 850 (3 Batteries Required)
Best Power Fortress LI 950 BAT-0063 (2 Batteries Required)	Sola 450 (2 Batteries Required)	Tripp Lite PS8.0 (2 Batteries Required)
Best Power PATRIOT Pro 1000 (3 Batteries Required)	Sola 450VA (2 Batteries Required)	Tripp Lite SMART 1050 (4 Batteries Required)
Best Power PATRIOT SPS650 (2 Batteries Required)	Sola 510 (1 Battery Required)	Tripp Lite SMART 1050RM (3 Batteries Required)
Best Technologies 1950VAB (1 Battery Required)	Sola 520VA (1 Battery Required)	Tripp Lite SMART 1050XL (5 Batteries Required)
Best Technologies 9909076 (1 Battery Required)	Sola 540014000000 (1 Battery Required)	Tripp Lite SMART 1250 (6 Batteries Required)
Best Technologies Fortress 250 (1 Battery Required)	Sola 5601101121501 (1 Battery Required)	Tripp Lite SMART 1250RM (6 Batteries Required)
Best Technologies Fortress II LI2250 (8 Batteries Required)	Sola 561A5064R118 (1 Battery Required)	Tripp Lite SMART 1400 (6 Batteries Required)
Best Technologies Fortress LI 2250 (8 Batteries Required)	Sola 91201096100210 (1 Battery Required)	Tripp Lite SMART 1400RM 120V (5 Batteries Required)
Best Technologies Fortress Rack Mount LI 1800 (Requires 8 Batteries)	Sola N-250 (2 Batteries Required)	Tripp Lite SMART 1400RM (6 Batteries Required)
Best Technologies Fortress Rack Mount LI 2250 (Requires 8 Batteries)	Sola Network 600KVA (1 Battery Required)	Tripp Lite SMART 500 (2 Batteries Required)
Compaq R3000 (16 Batteries Required)	Sola NETWORK UPS N1300 (8 Batteries Required)	Tripp Lite SMART 600 (3 Batteries Required)
Compaq T1000 (4 Batteries Required)	Sola S32200 (8 Batteries Required)	Tripp Lite SMART 675 (3 Batteries Required)
Compaq T2000 (8 Batteries Required)	Sola SPS1500 (1 Battery Required)	Tripp Lite SMART 675 Later Model (2 Batteries Required)
Compaq UPS 3000(16 Batteries Required)	Sola SPS250 (1 Battery Required)	Tripp Lite SMART 700 RM (3 Batteries Required)
CSR CSR400 (1 Battery Required)	Sola SPS/R 1000A (1 Battery Required)	Tripp Lite SMART 700XL (5 Batteries Required)
Data Shield PC200 (2 Batteries Required)	Sola SPS/R1500 (1 Battery Required)	Tripp Lite SMART 750 (3 Batteries Required)
Data Shield ST 450-1 (2 Batteries Required)	Sola SPS/R 150098 (1 Battery Required)	Tripp Lite SMART 750RM (3 Batteries Required)
Data Shield ST 550-1 (2 Batteries Required)	Sola SPS/R1500A (1 Battery Required)	Tripp Lite SMART 850 (4 Batteries Required)
Data Shield ST550 (2 Batteries Required)	Topaz 32200 (8 Batteries Required)	Tripp Lite SMART 850A (3 Batteries Required)
Data Shield TURBO 2+ (1 Battery Required)	Topaz 32200R (8 Batteries Required)	Tripp Lite SMART 850RM (3 Batteries Required)
Data Shield TURBO 2+450 (2 Batteries Required)	Topaz 800 (4 Batteries Required)	Tripp Lite SMART 900 (4 Batteries Required)
Deltech Powerright Pro II (4 Batteries Required)	Toshiba 310 (1 Battery Required)	Tripp Lite SMART PRO Net 1050 (4 Batteries Required)
Deltech PR450 (2 Batteries Required)	Tripp Lite 1400 (6 Batteries Required)	Tripp Lite SMART PRO Net 1400 (6 Batteries Required)
Deltech PRA1000A (4 Batteries Required)	Tripp Lite 675 (2 Batteries Required)	Tripp Lite SMART PRO Net 700 Net (2 Batteries Required)
Deltech PRB650 (2 Batteries Required)	Tripp Lite BC1050 (4 Batteries Required)	Tripp Lite SMART Unison MPS2000 (8 Batteries Required)
Deltech PRC1000 (2 Batteries Required)	Tripp Lite BC 200 (2 Batteries Required)	Tripp Lite SMART Unison PS1000 (4 Batteries Required)
Deltech PRC3000-RM (16 Batteries Required)	Tripp Lite BC200 (2 Batteries Required)	Unisys Omni Smart 1400 (4 Batteries Required)
Deltech PRK450 (2 Batteries Required)	Tripp Lite BC200A (2 Batteries Required)	Unisys PS1000 (4 Batteries Required)
Deltech PRK600 (2 Batteries Required)	Tripp Lite BC425INT/230 (3 Batteries Required)	Unisys UP909 (4 Batteries Required)
Deltech PRM1000 (4 Batteries Required)	Tripp Lite BC450DLAN (3 Batteries Required)	Upsonic LAN 75 (2 Batteries Required)
Deltech RCI000 (2 Batteries Required)	Tripp Lite BC450LAN (3 Batteries Required)	Upsonic LAN 75A (2 Batteries Required)
Elgar IPS600AI (3 Batteries Required)	Tripp Lite BC500/230 (3 Batteries Required)	Upsonic PCM 80 (2 Batteries Required)
Elgar IPS/A.I.1280US (6 Batteries Required)	Tripp Lite BC500 (3 Batteries Required)	Upsonic PCM 80VR (2 Batteries Required)
Elgar SPR350 (4 Batteries Required)		Upsonic Station 140A (2 Batteries Required)
Emerson 300 - (4 Batteries Required)		Upsonic Station 90 (2 Batteries Required)
Hewlett Packard 4629A (4 Batteries Required)		Upsonic UPS 300 (2 Batteries Required)
Hewlett Packard 600 (2 Batteries Required)		

Compatible With:	APC RBC3 (2 battery required)		
	APC RBC52 (1 battery required)		
Comments			
	Wide terminal version of Panasonic LC-R0612P battery. Fitted with faston 250 terminals (6.3mm wide). Ideal for UPS systems requiring this battery size. For faston 187 terminal size (4.8mm wide) please refer to Panasonic LC-R0612P		
Data Sheet			