



# LC-R0612P1

Model No	LC-R0612P1
Selling Unit	EACH
Description	LC-R0612P1 Panasonic Sealed Lead Acid Battery
Application	Cyclic & Standby, UPS, Security, Alarm, Instrument, Test Equipment, Toy, Medical Equipment
Chemistry	Sealed Lead
Voltage	6V
Watt Hour	72Wh
Watts Per Cell	64W
Nominal Capacity	12Ah
Termination	F2, Faston 250 6.3mm (0.25") spade terminals
Width	50mm
Height	94mm
Length/Breadth/Depth	151mm
Weight	1950g
Outer Quantity	12

Suitable For:

<b>Alpha Technologies</b> 2000 (4 Batteries Required)	<b>Hewlett Packard</b> Powertrust (4 Batteries Required)	<b>Tripp Lite</b> BC500INT (2 Batteries Required)
<b>APC</b> 450AT (2 Batteries Required)	<b>Liebert</b> PowerSure Interactive PS 2200MT (8 Batteries Required)	<b>Tripp Lite</b> BC 500 Internet (2 Batteries Required)
<b>APC</b> 450AT+ (2 Batteries Required)	<b>Liebert</b> PowerSure Interactive PS 2200RM (8 Batteries Required)	<b>Tripp Lite</b> BC550 (1 Battery Required)
<b>APC</b> 520ES (2 Batteries Required)	<b>Liebert</b> Up Station D S2200MT (8 Batteries Required)	<b>Tripp Lite</b> BC600 (3 Batteries Required)
<b>APC</b> 550ES (2 Batteries Required)	<b>Liebert</b> Up Station D UD1400VA (6 Batteries Required)	<b>Tripp Lite</b> BC600A (3 Batteries Required)
<b>APC</b> 800RT (2 Batteries Required)	<b>Oneac</b> ON900 (4 Batteries Required)	<b>Tripp Lite</b> BC600B/230 (3 Batteries Required)
<b>APC</b> AP166 (2 Batteries Required)	<b>Oneac</b> ON900A (4 Batteries Required)	<b>Tripp Lite</b> BC600B (3 Batteries Required)
<b>APC</b> AP250 (3 Batteries Required)	<b>Oneac</b> Series E One2000 (2 Batteries Required)	<b>Tripp Lite</b> BC600BLAN (3 Batteries Required)
<b>APC</b> AP450 (2 Batteries Required)	<b>Opti</b> 1000 (1 Battery Required)	<b>Tripp Lite</b> BC600INT (3 Batteries Required)
<b>APC</b> AP520 (2 Batteries Required)	<b>Opti</b> 1000E (3 Batteries Required)	<b>Tripp Lite</b> BC600LAN (3 Batteries Required)
<b>APC</b> AP800 (4 Batteries Required)	<b>Opti</b> 1BP210 (1 Battery Required)	<b>Tripp Lite</b> BC600NOV (3 Batteries Required)
<b>APC</b> AP800RT (4 Batteries Required)	<b>Opti</b> ONEBP210 (1 Battery Required)	<b>Tripp Lite</b> BC675 Internet (1 Battery Required)
<b>APC</b> AP900 (4 Batteries Required)	<b>Pacific Power</b> VANGUARD (2 Batteries Required)	<b>Tripp Lite</b> BC675 PRO (1 Battery Required)
<b>APC</b> APC450 (2 Batteries Required)	<b>Parasystems</b> MINUTEMAN A1250/2 (4 Batteries Required)	<b>Tripp Lite</b> BC Internet 675 (2 Batteries Required)
<b>APC</b> BACK-UPS 450 (2 Batteries Required)	<b>Parasystems</b> MINUTEMAN A1250 (4 Batteries Required)	<b>Tripp Lite</b> BC PERS 500 (2 Batteries Required)
<b>APC</b> BACK-UPS 600 (2 Batteries Required)	<b>Parasystems</b> MINUTEMAN A2000 (6 Batteries Required)	<b>Tripp Lite</b> BC Personal 500 NEW (2 Batteries Required)
<b>APC</b> BACK-UPS 650 (BK650MC) (2 Batteries Required)	<b>Parasystems</b> MINUTEMAN A500/2 (2 Batteries Required)	<b>Tripp Lite</b> BC Personal 500 OLD (1 Battery Required)
<b>APC</b> BACK-UPS 900 (4 Batteries Required)	<b>Parasystems</b> MINUTEMAN A500 (2 Batteries Required)	<b>Tripp Lite</b> BC PRO 1050 (4 Batteries Required)
<b>APC</b> BACK-UPS BK450 (2 Batteries Required)	<b>Parasystems</b> MINUTEMAN A900/2 (4 Batteries Required)	<b>Tripp Lite</b> BC PRO 1400 (5 Batteries Required)
<b>APC</b> BACK-UPS BK520 (2 Batteries Required)	<b>Parasystems</b> MINUTEMAN A900 (4 Batteries Required)	<b>Tripp Lite</b> BC PRO 550 (2 Batteries Required)
<b>APC</b> BACK-UPS BK575C (2 Batteries Required)	<b>Para Systems</b> MINUTEMAN 250XL (2 Batteries Required)	<b>Tripp Lite</b> BC PRO 675 (2 Batteries Required)
<b>APC</b> BACK-UPS BK600 (2 Batteries Required)	<b>Para Systems</b> MINUTEMAN 500 (4 Batteries Required)	<b>Tripp Lite</b> BC PRO 850 (3 Batteries Required)
<b>APC</b> BACK-UPS BK600C (2 Batteries Required)	<b>Para Systems</b> MINUTEMAN 550 (4 Batteries Required)	<b>Tripp Lite</b> BC PRO Internet 1050 (1 Battery Required)
<b>APC</b> BACK-UPS BK900 (4 Batteries Required)	<b>Powerware</b> PowerWare 2000 (20 Batteries Required)	<b>Tripp Lite</b> BC PRO Internet 1050 (1 Battery Required)
<b>APC</b> NS2200RM3U (2 Batteries Required)	<b>Powerware</b> Powerware PW3115-650 (2 Batteries Required)	<b>Tripp Lite</b> BC PRO T2+520 (2 Batteries Required)
<b>APC</b> NS3000RM3U (2 Batteries Required)	<b>Powerware/Exide</b> Exide PW 3115-650 (2 Batteries Required)	<b>Tripp Lite</b> BC PRO T2+520 (2 Batteries Required)
<b>APC</b> NS3000RM3U (2 Batteries Required)	<b>Safe</b> 1200 (8 Batteries Required)	<b>Tripp Lite</b> Internet Office 700 (2 Batteries Required)
<b>APC</b> PCNET (2 Batteries Required)	<b>Safe</b> 1200A (8 Batteries Required)	<b>Tripp Lite</b> MISC TMC TE300 (3 Batteries Required)
<b>APC</b> POWERCELL NETWORK POWERCELL (2 Batteries Required)	<b>Safe</b> 250 (2 Batteries Required)	<b>Tripp Lite</b> MISC TMC TE300 Later (1 Battery Required)
<b>APC</b> RBK520 (2 Batteries Required)	<b>Safe</b> 400 (4 Batteries Required)	<b>Tripp Lite</b> MISC TMC TE700A (5 Batteries Required)
<b>APC</b> RBK900 (2 Batteries Required)	<b>Safe</b> 400A (4 Batteries Required)	<b>Tripp Lite</b> OMNI 500 LAN (2 Batteries Required)
<b>APC</b> SMART-UPS 450 (AP450) (2 Batteries Required)	<b>Safe</b> 425 (4 Batteries Required)	<b>Tripp Lite</b> OMNI 600/230 (2 Batteries Required)
<b>APC</b> SMART-UPS 520 (AP520) (2 Batteries Required)	<b>Safe</b> 425A (4 Batteries Required)	<b>Tripp Lite</b> OMNI 675 (2 Batteries Required)
<b>APC</b> SMART-UPS 750VA (DLA750) (2 Batteries Required)	<b>Safe</b> 500 (4 Batteries Required)	<b>Tripp Lite</b> OMNI PRO 675 (2 Batteries Required)
<b>APC</b> SMART-UPS 750VA USB and SER (SUA750RM1U) (4 Batteries Required)	<b>Safe</b> 500A (4 Batteries Required)	<b>Tripp Lite</b> OMNI PRO Network Pro 1050 (4 Batteries Required)
<b>APC</b> SMART-UPS 750VA USB (SUA750) (2 Batteries Required)	<b>Safe</b> FES200A (4 Batteries Required)	<b>Tripp Lite</b> OMNI PRO Network Pro 1400 (5 Batteries Required)
<b>APC</b> SMART-UPS 900 (4 Batteries Required)	<b>Safe</b> SM1400 (8 Batteries Required)	<b>Tripp Lite</b> OMNI PRO Network Pro 675 (2 Batteries Required)
<b>APC</b> SMART-UPS SU900 (4 Batteries Required)	<b>Safe</b> SM800 (4 Batteries Required)	<b>Tripp Lite</b> OMNI PRO Network Pro 850 (3 Batteries Required)
<b>APC</b> UPS520EST (2 Batteries Required)	<b>Safe</b> SPS1000 (8 Batteries Required)	<b>Tripp Lite</b> OMNI SMART 1050 (4 Batteries Required)
<b>APS</b> 6001 (2 Batteries Required)	<b>Safe</b> STS200-117 (1 Battery Required)	<b>Tripp Lite</b> OMNI SMART 1400 (5 Batteries Required)
<b>Best Power</b> Fortress LI 1020 BAT-0063 (2 Batteries Required)	<b>Sola</b> 056-00208-000-26 (450VA) (2 Batteries Required)	<b>Tripp Lite</b> OMNI SMART 650 (3 Batteries Required)
<b>Best Power</b> FORTRESS LI 1800 BAT-0063 (8 Batteries Required)	<b>Sola</b> 290352210 (1 Battery Required)	<b>Tripp Lite</b> OMNI SMART 675 (2 Batteries Required)
<b>Best Power</b> FORTRESS LI 2250 BAT-0063 (8 Batteries Required)	<b>Sola</b> 32200 (8 Batteries Required)	<b>Tripp Lite</b> OMNI SMART 725 (1 Battery Required)
<b>Best Power</b> Fortress LI 750 BAT-0063 (2 Batteries Required)	<b>Sola</b> 325 1000VA (3 Batteries Required)	<b>Tripp Lite</b> OMNI SMART 850 (3 Batteries Required)
<b>Best Power</b> Fortress LI 950 BAT-0063 (2 Batteries Required)	<b>Sola</b> 400VA (2 Batteries Required)	<b>Tripp Lite</b> OMNI SMART 850 (3 Batteries Required)
<b>Best Power</b> PATRIOT Pro 1000 (3 Batteries Required)	<b>Sola</b> 450 (2 Batteries Required)	<b>Tripp Lite</b> OMNI SMART 850 (3 Batteries Required)
<b>Best Power</b> PATRIOT SPS650 (2 Batteries Required)	<b>Sola</b> 450VA (2 Batteries Required)	<b>Tripp Lite</b> PS8.0 (2 Batteries Required)
<b>Best Technologies</b> 1950VAB (1 Battery Required)	<b>Sola</b> 510 (1 Battery Required)	<b>Tripp Lite</b> SMART 1050 (4 Batteries Required)
<b>Best Technologies</b> 9909076 (1 Battery Required)	<b>Sola</b> 520VA (1 Battery Required)	<b>Tripp Lite</b> SMART 1050RM (3 Batteries Required)
<b>Best Technologies</b> Fortress 250 (1 Battery Required)	<b>Sola</b> 540014000000 (1 Battery Required)	<b>Tripp Lite</b> SMART 1050XL (5 Batteries Required)
<b>Best Technologies</b> Fortress II LI2250 (8 Batteries Required)	<b>Sola</b> 5601101121501 (1 Battery Required)	<b>Tripp Lite</b> SMART 1250 (6 Batteries Required)
<b>Best Technologies</b> Fortress LI 2250 (8 Batteries Required)	<b>Sola</b> 561A5064R118 (1 Battery Required)	<b>Tripp Lite</b> SMART 1250RM (6 Batteries Required)
<b>Best Technologies</b> Fortress Rack Mount LI 1800 (Requires 8 Batteries)	<b>Sola</b> 91201096100210 (1 Battery Required)	<b>Tripp Lite</b> SMART 1400 (6 Batteries Required)
<b>Best Technologies</b> Fortress Rack Mount LI 2250 (Requires 8 Batteries)	<b>Sola</b> N-250 (2 Batteries Required)	<b>Tripp Lite</b> SMART 1400RM 120V (5 Batteries Required)
<b>Compaq</b> R3000 (16 Batteries Required)	<b>Sola</b> Network 600KVA (1 Battery Required)	<b>Tripp Lite</b> SMART 1400RM (6 Batteries Required)
<b>Compaq</b> T1000 (4 Batteries Required)	<b>Sola</b> NETWORK UPS N1300 (8 Batteries Required)	<b>Tripp Lite</b> SMART 500 (2 Batteries Required)
<b>Compaq</b> T2000 (8 Batteries Required)	<b>Sola</b> S32200 (8 Batteries Required)	<b>Tripp Lite</b> SMART 600 (3 Batteries Required)
<b>Compaq</b> UPS 3000(16 Batteries Required)	<b>Sola</b> SPS1500 (1 Battery Required)	<b>Tripp Lite</b> SMART 675 (3 Batteries Required)
<b>CSR</b> CSR400 (1 Battery Required)	<b>Sola</b> SPS250 (1 Battery Required)	<b>Tripp Lite</b> SMART 675 Later Model (2 Batteries Required)
<b>Data Shield</b> PC200 (2 Batteries Required)	<b>Sola</b> SPS/R 1000A (1 Battery Required)	<b>Tripp Lite</b> SMART 700 RM (3 Batteries Required)
<b>Data Shield</b> ST 450-1 (2 Batteries Required)	<b>Sola</b> SPS/R1500 (1 Battery Required)	<b>Tripp Lite</b> SMART 700XL (5 Batteries Required)
<b>Data Shield</b> ST 550-1 (2 Batteries Required)	<b>Sola</b> SPS/R 150098 (1 Battery Required)	<b>Tripp Lite</b> SMART 750 (3 Batteries Required)
<b>Data Shield</b> ST550 (2 Batteries Required)	<b>Sola</b> SPS/R1500A (1 Battery Required)	<b>Tripp Lite</b> SMART 750RM (3 Batteries Required)
<b>Data Shield</b> TURBO 2+ (1 Battery Required)	<b>Topaz</b> 32200 (8 Batteries Required)	<b>Tripp Lite</b> SMART 850 (4 Batteries Required)
<b>Data Shield</b> TURBO 2+450 (2 Batteries Required)	<b>Topaz</b> 32200R (8 Batteries Required)	<b>Tripp Lite</b> SMART 850A (3 Batteries Required)
<b>Deltech</b> Powerright Pro II (4 Batteries Required)	<b>Topaz</b> 800 (4 Batteries Required)	<b>Tripp Lite</b> SMART 850RM (3 Batteries Required)
<b>Deltech</b> PR450 (2 Batteries Required)	<b>Toshiba</b> 310 (1 Battery Required)	<b>Tripp Lite</b> SMART 900 (4 Batteries Required)
<b>Deltech</b> PRA1000A (4 Batteries Required)	<b>Tripp Lite</b> 1400 (6 Batteries Required)	<b>Tripp Lite</b> SMART PRO Net 1050 (4 Batteries Required)
<b>Deltech</b> PRB650 (2 Batteries Required)	<b>Tripp Lite</b> 675 (2 Batteries Required)	<b>Tripp Lite</b> SMART PRO Net 1400 (6 Batteries Required)
<b>Deltech</b> PRC1000 (2 Batteries Required)	<b>Tripp Lite</b> BC1050 (4 Batteries Required)	<b>Tripp Lite</b> SMART PRO Net 700 Net (2 Batteries Required)
<b>Deltech</b> PRC3000-RM (16 Batteries Required)	<b>Tripp Lite</b> BC 200 (2 Batteries Required)	<b>Tripp Lite</b> SMART Unison MPS2000 (8 Batteries Required)
<b>Deltech</b> PRK450 (2 Batteries Required)	<b>Tripp Lite</b> BC200 (2 Batteries Required)	<b>Tripp Lite</b> SMART Unison PS1000 (4 Batteries Required)
<b>Deltech</b> PRK600 (2 Batteries Required)	<b>Tripp Lite</b> BC200A (2 Batteries Required)	<b>Unisys</b> Omni Smart 1400 (4 Batteries Required)
<b>Deltech</b> PRM1000 (4 Batteries Required)	<b>Tripp Lite</b> BC425INT/230 (3 Batteries Required)	<b>Unisys</b> PS1000 (4 Batteries Required)
<b>Deltech</b> RCI000 (2 Batteries Required)	<b>Tripp Lite</b> BC450DLAN (3 Batteries Required)	<b>Unisys</b> UP909 (4 Batteries Required)
<b>Elgar</b> IPS600AI (3 Batteries Required)	<b>Tripp Lite</b> BC450LAN (3 Batteries Required)	<b>Upsonic</b> LAN 75 (2 Batteries Required)
<b>Elgar</b> IPS/A.I.1280US (6 Batteries Required)	<b>Tripp Lite</b> BC500/230 (3 Batteries Required)	<b>Upsonic</b> LAN 75A (2 Batteries Required)
<b>Elgar</b> SPR350 (4 Batteries Required)	<b>Tripp Lite</b> BC500 (3 Batteries Required)	<b>Upsonic</b> PCM 80 (2 Batteries Required)
<b>Emerson</b> 300 - (4 Batteries Required)		<b>Upsonic</b> PCM 80VR (2 Batteries Required)
<b>Hewlett Packard</b> 4629A (4 Batteries Required)		<b>Upsonic</b> Station 140A (2 Batteries Required)
<b>Hewlett Packard</b> 600 (2 Batteries Required)		<b>Upsonic</b> Station 90 (2 Batteries Required)
		<b>Upsonic</b> UPS 300 (2 Batteries Required)

Compatible With:	APC RBC3 (2 battery required)		
	APC RBC52 (1 battery required)		
Comments			
	Wide terminal version of Panasonic LC-R0612P battery. Fitted with faston 250 terminals (6.3mm wide). Ideal for UPS systems requiring this battery size. For faston 187 terminal size (4.8mm wide) please refer to Panasonic <a href="#">LC-R0612P</a>		
Data Sheet			